

Note: iPhone 5 chargers now also available.

Phone models supported by the chargers available from SFU's Bennett Library Loans counter.



iPhone: 4, 3GS, 3G
Classic, iPod 5G, 4G iPod nano 6G, 5G, 4G, 3G, 2G, 1G, iPod Touch 4G, 3G, 2G, 1G

Mini USB

Motorola: RAZR V3, RAZR V3xx, KRZR K1, Q9m, W385, RAZR maxx V6, SLVRL7c, W315, KRZR K1m, Q, RAZR V3m, RIZR Z3, RAZR V3i, RAZR V3t, RAZRV3e, RAZR V3r, V195, V197, RAZR V3a, V325, V323i, V325i, C290.L2, W490/W510/W5, ROKR Z6m, RIZR Z6t, SLVR L9 / L72, RAZR V3c, Z6cWorld Edition, W375, W395, Z6w, W175, SLVR L7, Q9c, W755, W376 / W377, W370, VU204, ACTV W450, VE240, W260g, VA76r Tundra, W233 Renew, EM330 /EM28, i290, VE465

Motorola iDen / Nextel: ic902 Deluxe, ic402 Blend, ic502 Buzz, ic602Bbuzz+, i425
MOTOROLA:A1200/A688/A732/A780/E1070/E2/E/E6/E80/E860/E770/K1/K3/L2/L6/L9/L6/L1/L7/L7/L2/MPX200/U6 /U6C/V191/V3/V320/V360/V30i/V3m/V3x/W208/W220/W375/i335

MOTOROLA:Z3/A120e/A1200/A1208/A1800/A688/A810/A910/C308/C362/C363/C450/E1070/E375/K1M/KRZR K1/L7/L7/L9/L9/MS
500/RIZRZ8/U8/V1150/V190/V191/V195/V360i/V3XX/V750/VE75/W210/W230/W360/W371/W380/W395/W510/Z10/Z6/Z8
BlackBerry:7150/7280/7730/ 8830, 8700c, 8700g, 8800, 8300 Curve, 8310 Curve, 8320 Curve, 8703e, 7100i, 7100g, 7105t, 7290, 7230, 8100Pearl, 8820, 7130e, 7130c, 7130g, 8120 Pearl, 8330 Curve, 8110 Pearl,Bold 9000, Curve 8350i
HTC: Dash 3G (GSM), myTouch 3G / Magic, Touch Pro2 (CDMA), Touch Pro2(GSM), Hero (CDMA) /TOUCH HD

LG

Cell phones: LG AN230, LG AX260, LG AX275, LG AX380, LG AX565, LGAX8600, LG CB630, LG CE110, LG CG180, LG Chioow, LG CHOCOLATE, LGCookie, LG CP150, LG CU515, LG CU575, LG CU720, LG CU915, LG CU920, LGGenV, LG Flair, LG GT365 Neon, LG Invision, LG KE970 Shine, LGK6800 Chocolate, LG LG230, LG LG600G, LG LN240, LG LX150, LG LX160, LG LX165, LG LX570, LG Muziq, LG Prada, LG RUMOR, LG Satrum, LG Scoop, LGShine, LG Trax, LG UN430, LG UX260, LG UX380, LG UX565, LG Venus, LGVoyager, LG Vu, LG vuTV, LG VX10000, LG VX5400, LG VX8350, LG VX8500, LG VX8550, LG VX8600, LG VX8700, LG VX8800, LG VX9400, LG VX9900, LGWave, LG Wine 2
Bluetooth Headsets: LG HBM-730, HBM-770, HBS-200

Sony Ericsson

30c/300i/c3310/c3702/c905i/d750/d750i/j100/j100c/j110c/j120c/j220c/j230/j230c/j230k200c/k220c/k220i/k310c/k310i/k320i/k510/k510c/k510i/k530i/k550c/k610/k610c/k610i/k618/k618i/k620i/k630/k660/k750/k750c/k750i/k758/k758c/k770i/k790i/k790c/k790i/k800/k800c/k800i/k810/k810c/k818c/k850/k858c/m600/m600i/m608/m608c/p1c/p1c/p1p1p700/p990/p990c/p990i/300i/s500i/s500c/s500i/s200c/w200c/w300/w300c/w300i/w350c/w350i/w550/w550c/w550i/w580c/w580i/w600/w600c/w600i/w610c/w660i/w700/w700c/w700i/w710/w710c/w710i/w760c/w800/w800c/w800i/w810/w810c/w818i/w830/w830c/w830i/w850/w850c/w850i/w880/w880i/w888c/w890i/w898/w900/w900c/w900i/w908/w908c/w910/w910i/w950/w950c/w958/w958c/w999i/z520/z520c/z520i/z530c/z530i/z550c/z550i/z558c/z710/z710c/z710i/z780/

Sony PSP

Samsung ATAD820C: 6V/700mA

c3050c/c3310/c3702/c905i/d750/d750i/j100/j100c/j110c/j120c/j220c/j230/j230c/j230k200c/k220c/k220i/k310c/k310i/k320i/k510/k510c/k510i/k530i/k550c/k610/k610c/k610i/k618/k618i/k620i/k630/k660/k750/k750c/k750i/k758/k758c/k770i/k790i/k790c/k790i/k800/k800c/k800i/k810/k810c/k818c/k850/k858c/m600/m600i/m608/m608c/p1c/p1c/p1p1p700/p990/p990c/p990i/300i/s500i/s500c/s500i/s200c/w200c/w300/w300c/w300i/w350c/w350i/w550/w550c/w550i/w580c/w580i/w600/w600c/w600i/w610c/w660i/w700/w700c/w700i/w710/w710c/w710i/w760c/w800/w800c/w800i/w810/w810c/w818i/w830/w830c/w830i/w850/w850c/w850i/w880/w880i/w888c/w890i/w898/w900/w900c/w900i/w908/w908c/w910/w910i/w950/w950c/w958/w958c/w999i/z520/z520c/z520i/z530c/z530i/z550c/z550i/z558c/z710/z710c/z710i/z780/

Nintendo DS

Nintendo 3DS, DSI, DSI XL

Nintendo DS Lite

Micro USB

BlackBerry: Playbook, 8220 (Pearl Flip), 8230 (Pearl Flip), 8520 (Curve), 8530 (Curve), 8900 (Curve), 9100 (Pearl 3G), 9300 (Curve 3G), 9330 (Curve 3G), 9500 (Storm), 9530 (Storm), 9550 (Storm2), 9630 (Tour), 9650 (Bold), 9670 (Style), 9700 (Bold), 9780 (Bold), 9800 (Torch)
Casio: C751 (G'zOne Ravine)
Cricet: AA10 (TXTM8 3G), M6000 (Zio)

Google: Nexus One
Hewlett-Packard: IPAQ (Glisten), Veer, Pre 3, Pre 2
HTC: Wildfire S, Status /ChaCha, myTouch 4G Slide, 6350 Droid Incredible 2, Sensation 4G, Desire S, Merge CDMA G2, EVO 3D, Arrive, 7 Trophy, Freestyle, Desire HD, Inspire 4G, EVO Shift 6100 4G, ThunderBolt (Incredible HD 6400), Wildfire (CDMA), HD7, Surround T8788, myTouch 4G, G2, Desire, Aria, MyTouch 3G Slide, Evo 4G, Droid Incredible, HD2, myTouch 3G
Huawei: M735, M860 (Ascend), U8150 (Comet),
Kyocera: E1100 (Neo), E2000, E3100 (Rio), M1400 (Laylo), M2000 (X-TC), S1300 (Melo), S1310 (Domino), S2100, S2300 (Torino/Loft), S4000 (Mako),
LG: AX155, AX310, AX500 (Swift), AX585 (Rhythm), AX830, AX840 (Tritan), C900 (Quantum), CF360, CT810 (Incite), ENV2 (VX9100), GD570 (Dlite), GD710 (Shine II), GR500 (Xenon), GR700 (Vu Plus), GS170, GS390 (Prime), GS505 (Sentio), GT550 (Encore), GT950 (Arena), GU295/GU292, GW370 (Neon II), GW820 (eXpo), LN180, LN240 (Remarg), LX110 (Rumor Touch), LS670 (Optimus S), LW310 (Helix), LX265 (Rumor2), LX290, LX370, LX400, LX600 (Lotus), LX610 (Lotus Elite), MN180 (Imprint), MN240 (Imprint), MS690 (Optimus M), MT310, MT375 (Lyric), Optimus U, P509 (Optimus T), UN430 (Wine II), UN510 (Banter Touch), UN610 (Mystique), US740 (Apex), UX220, UX265 (Banter), UX280 (Wine), UX310, UX700 (Bliss), VM670 (Optimus V), VN250 (Cosmos), VX9600 (Versa) (Touch), VN530 (Octane), VS680 (Vortex), VS740 (Ally), VX11000 (enV Touch), VX5500, VX5600 (Accolade), VX7100 (Glance), VX8360, VX8370 (Cloud), VX8575 (Chocolate Touch), VX8610, VX9200 (enV3), VX9600 (Versa)

Motorola: A455 (Rival), A555 (Devour), A855 (Droid), A955 (Droid 2), Crush, E8, i1, i296, i410, i465 (Clitq), i576, i680 (Brute), i686 (Brute), i776, i856 (Debut), i886, i890, i9, MB200 (Clari), MB300 (Backflip), MB501 (Clitq XT), MB502 (Charm), MB508 (Flipside), MB511 (Flipout), MB520 (Bravo), MB525 (Defy), MB611 (CLIQ 2), MB810 (Droid X), MB860 (Olympus/Altix 4G), Q9h, QA1 (Karma), QA30 (Hint), QA4 (Evoke), RZ22 (Droid), V750, V8, V860 (Barrage), V9, V950, V9m, V9x, VE20, VE440, VU30, W766 (Entice), W845 (Quantico), WX404 (Grasp), WX445 (Citrus), XT610 (Droid Pro), Z8C, Z9, ZN4, ZN5 (zine),
Nokia: 1006, 1606, 2605, 2705 (Shade), 3606, 6205, 6350, 6750, 7205, 7705 (TWIST), E73 (Mode),
Palm: Pxi, Pxi Plus, Treo Pro, TREO800w,
Pantech: CDM8999 (Crux), P9050 (LASER),
Samsung: A187, A197, A597 (Eternity II), A667 (Evergreen), A687 (Strive), A797 (Flight), A817 (Solstice II), A847 (Rugby II), A897 (Mythic), A927 (Flight II), D700 (Epic 4G), i100 (Gem), i220 (Code), i225 (Exec), i350 (Intrepid), i400 (Continuum), i500 (Fascinata), i500 (Mesmerize), i897 (Capitivate), i917 (Focus), i920 (Omnia II), M220, M240, M320, M330, M350 (Seek), M360, M540 (Rant), M550 (Exclaim), M560 (Reclaim), M570 (Restore), M630 (Highnote), M850 (Instinct HD), M900 (Moment), M910 (Intercept), M920 (Transform), NXS (Nexus S), R100 (Stunt), R250 (Contour), R330 (Stride), R350 (Freeform), R351 (Freeform), R360 (Freeform II), R460 (MyShot II), R470 (TWOSTEP), R560 (Messenger II), R570 (Messenger III), R580 (Profile), R630 (Messenger Touch), R710 (Suede), R850 (Caliber), R860, R880 (Acclaim), R900 (Craft), R910 (Galaxy Indulge), T249, T259, T359, T369, T669 (Gravity T), T959 (Vibrant), T959V (Galaxy S 4G), U320 (Haven), U360 (Gusto), U460 (Intensity II), U820 (Reality),
Sanyo: 2700, 3810, 3820 (Vero), 6750 (Katana Eclipse), 6780 (Incognito), 6780 (Innuendo), E4100 (Taho), Katana LX, PRO200, PRO70, S1,
Sharp: FX, Kin One (Microsoft), Kin Two (Microsoft),
SonyEricsson: XPERIA X8, XPERIA X10 Mini Pro, Cedar J108A, Aspen, Vivaz pro, Xperia Play, Xperia X10 mini,
ZTE: 3200 (Peele), E520 (Agent), F160, F350 (Salute), R225

Nokia - 5V/2.0mm

Nokia:1209/1650/2505/2600c/2630/2680s/2760/2865/3109c/3110c/3152/3250/5000/5070/5200/5300/5310/5500/5700/6070/6080/6085/6086/6088/6101/6103/6110/6110n/6111/6125/6131/6151/6233/6234/6268/6270/6275/6280/6288/6290/6300/6500s/7360/7370/7373/7390/7500/8800s/e50i/e51/e61/e61i/e62/e65i/n70/n71/n72/7260/2760/2865/3110/3110c/3250/3500/3500c/3600s/3610a/5200/5220/5310c/5310xm/5320/5320xm/5710xm/6066/6070/6080/6102/6103/

All logos, trademarks and brand names are the property of their respective companies. ChargeAll is not affiliated with any of the listed compatible devices and brand names. "Made for iPod" "Made for iPhone" & "Made for iPad" means that an electronic accessory has been designed to connect specifically to the iPod/iPhone/iPad and has been certified by the developer to meet Apple performance standards. Apple is not responsible for the operation of this device or its compliance with safety and regulatory standards. Please note the use of this accessory with iPod, iPhone & iPad may affect wireless performance. iPod, iPod classic, iPod nano, iPod shuffle, iPod touch, iPhone and iPad are trademarks of Apple Inc., registered in the U.S. and other countries.

